

LXRack by TheatreDigitalized

For lighting operation and control, the user will automatically login on boot.



Connecting to EOS

For remote control via the EOS software through an iPad, tablet or phone – you can connect to the lighting desk by using the IP listed below by connecting to the local lighting network. The connection password for the EOS console is simply "LXRack".

Default User Access



For default login and EOS system access. This user has auto-login enabled.

Username: eos

Emergency Admin Access



For necessary use only, administrative access not required by default.

Username: mgr

Password: datahorde11

Internal Network Access



The following information will grant you access to the rack's internal network.

Mode: WPA2/PSK

SSID: Rainbow Connection

Password: TechNet5

Default IP Range: 10.0.0.1–10.0.0.255 10.0.0.2–10.0.0.1

Gateway: 10.0.0.1

Internal Network Connections



The following information is for those who need to access certain interfaces remotely.

Primary PC/EOS IP: 10.0.10

Artnet Node IP: 10.0.0.13

Pi IP: 10.0.0.12

LXRack by TheatreDigitalized

For lighting operation and control, the user will automatically login on boot.

Contact, questions & concerns



For any questions or concerns over the product you've hired, you're welcome to contact the support desk via any of the following methods of contact:

Email: [hires@theatredigitalized.com](mailto: hires@theatredigitalized.com)

Phone: +44 7706 698360

Twitter: @theatredigi